

Matrox RT2000

Installation procedure for the ATI 3D RAGE PRO as a secondary display

This document provides information for installing the ATI 3D RAGE PRO for use as a second display with Matrox RT2000.

Important Before installing your secondary display card, make sure that you've correctly installed and configured your RT2000 hardware and software as explained in your *RT2000 Installation & User Guide*.

To install your secondary display card

1. Power down your system, then install your ATI 3D RAGE PRO display card in a free PCI slot and connect your second computer monitor.
2. Restart your computer. A message will be displayed on your secondary monitor stating that your secondary display adapter has been initialized.
3. If you have a Windows Me system, Windows detects your new display card and installs its driver from the Windows database.
4. If you have a Windows 98 SE system, do the following when the "Add New Hardware Wizard" starts:
 - a. Click **Next**.
 - b. Choose to display a list of all drivers in a specific location so you can select the driver you want, then click **Next**.
 - c. Select your card type from the list: **ATI 3D RAGE PRO**, then click **Next**.
 - d. After the driver has been installed, click **Finish**.
5. Follow the instructions on the screen to complete the software installation.
6. Right-click your Windows desktop background, then choose **Properties > Settings**.
7. In the provided display window, click the number "2" monitor, then click **Yes** to enable the monitor.
8. Set your color palette (**Colors**) and display resolution (**Screen area**) to the same settings as your primary monitor. For more information on Windows monitor settings and changing your Windows Display Properties, see your Windows documentation.

Notes

- If you have a Windows Me system, the installed driver version should be 4.10.00.3000. If you have a Windows 98 SE system, the installed driver version should be 4.10.1720. To verify your driver version, right-click your Windows desktop background, then choose **Properties>Settings>Advanced>Adapter>Properties>Driver**.
- Video playback on your second computer monitor may be slow and jerky. When playing back clips in Adobe Premiere, leave the **Monitor** and **Clip** windows on your primary monitor (that is, the monitor connected to your Matrox Millennium Flex 3D Edition card).
- Your ATI 3D RAGE PRO is **not** supported as a secondary display card under Windows 2000.

© 2001 by Matrox Electronic Systems Ltd. All rights reserved.

Disclaimer Matrox Electronic Systems Ltd. reserves the right to make changes in specifications at any time and without notice. The information provided by this document is believed to be accurate and reliable. However, no responsibility is assumed by Matrox Electronic Systems Ltd. for its use; nor for any infringements of patents or other rights of third parties resulting from its use. No license is granted under any patents or patent rights of Matrox Electronic Systems Ltd.